

⚠️ ENSURE FIREARM IS UNLOADED

- 1** Install Hot Button™ to M-LOK™ Rail. Finger tighten bolts, then 1/8 – 1/4 turn to set. **DO NOT EXCEED 35 IN-LBS ON METAL RAIL, OR 15 IN-LBS ON POLYMER RAIL.** Ensure M-LOK™ nuts are fully perpendicular to M-LOK™ slots in rail (fully seated).
- 2** Route cable from Hot Button™ to light or laser device and fully seat plug in socket. Avoid sharp bends in cable and routing over extreme heat areas and sharp edges.

