

⚠ ENSURE FIREARM IS UNLOADED**⚠ WARNING:** Over-torquing fasteners can damage your mount and will not be covered by warranty.

1 Install Hot Button™ to M-LOK™ Rail. Lightly snug all screws before applying torque to any. **DO NOT EXCEED 35 IN-LBS ON METAL RAIL, OR 15 IN-LBS ON POLYMER RAIL.** Ensure M-LOK™ nuts are fully perpendicular to M-LOK™ slots in rail (fully seated).

2 Route cable from Hot Button™ to light or laser device and fully seat plug in socket. Avoid sharp bends in cable and routing over extreme heat areas and sharp edges.

